

Tips when installing a Nohr-S Polyurea Coating® Kit

Tip #1

- Use a primer!
 - Primer will penetrate further into the concrete
 - Primer improves finish and coverage
 - Helps to eliminate bubbling!
 - Bubbling can be caused by a porous substrate
 - Bubbling can be caused by substrate or surface moisture
 - Bubbling can be caused by brisk air movement while curing
 - Bubbling can be caused by hot-sun while curing
 - Our kits avoid these issues because our included primer helps eliminate these issues!!

Tip #2

- Use a paint tray!
 - Although tempting, don't POUR polyurea onto the floor
 - It will dry too quickly, leaving high spots in the surface
 - Purchase disposable paint trays to save \$\$

Tip #3

- Flake While you roll!
 - Although our Nohr-S Polyurea® is stable in the can or tray, it does dry fast once on the floor
 - Have a 2nd person flake the floor as you roll
 - Two pairs of hands always make the work easier!

Tip #4

- Prepare the weekend before!
 - If any repairs are needed, you have time to perform them
 - Prep can take longer than expected
 - If you power-wash the floor it will have time to properly dry